



Natural stone care and maintenance

1. Before you caulk the top to the cabinet and sinks, make sure to use 100% latex/silicon caulk that is labeled for kitchen and bath (or stones). **DO NOT to use any Acrylic Caulking** (for doors, window, trim...) in this project as acrylic caulk will leak through the thickness of natural stone slab and give you uneven looks. If you are not sure what to use, consult with your local hardware store for best caulk to use for natural stones.
2. Once you have caulked the top to the cabinet and the sinks, you need to seal the top before normal use. Please consult your local hardware store for stone sealant and follow the directions on the bottle. Test it at a corner before applying to the entire surface.
3. Stone sealant needs to be applied periodically to preserve the stone and prevent staining. Please follow the direction on the sealant bottle for details.